

Ucho Pro



How to use Ucho Pro

1. Plug Ucho Pro into the XLR inputs on your device.
2. Turn on the phantom power. On some devices phantom power needs to be turned on via button or menu option. Consult the manual if you're not sure how to do it.
3. Set your gain to appropriate level and enjoy!

[How to attach clips to Uši microphones](#)

Technical specifications

Phantom powered, matched stereo pair of pre-polarized condenser microphones	
Cable	1.5 m (for each mic) with XLR connector
Maximum input pressure level	~122 dB SPL
Sensitivity	-28 dB at 1kHz (± 3 dB)
Self-noise	~14 dBA

From:
<http://knowledge.lom.audio/> - **LOM knowledge base**

Permanent link:
<http://knowledge.lom.audio/manuals/uchopro?rev=1503060002>

Last update: **2017/08/18 14:40**

