

Uši user manual



How to use Uši

You will need a recorder or a sound card with plug-in power input. Usually this is represented by “mic in” mini-jack input.

1. Plug Uši into your recorders “mic in”.
2. Make sure that plug-in power is on.
3. On some recorders this needs to be set up using internal menus. Consult the recorders manual if you're not sure.
4. Set your gain to appropriate levels and enjoy!

[How to attach clips to Uši microphones](#)

Technical specifications

Matched stereo pair of pre-polarized condenser microphones

Cable: 1.5 m (for each mic) with 3.5 mm (1/8”) jack

Impedance: 2.4 k Ω at 1kHz

Maximum input pressure level: ~122 dB SPL

Sensitivity: -28 dB at 1kHz (± 3 dB)

Self-noise: 14-17 dBA

From:

<http://knowledge.lom.audio/> - **LOM knowledge base**

Permanent link:

<http://knowledge.lom.audio/manuals/usi?rev=1470837969>

Last update: **2016/08/10 16:06**

