

Uši user manual



How to use Uši


You will need a recorder or a sound card with plug-in power input. Usually this is represented by “mic in” mini-jack input.

1. Plug Uši into your recorders “mic in”.
2. Make sure that plug-in power is on.
3. On some recorders this needs to be set up using internal menus. Consult the recorders manual if you're not sure.
4. Set your gain to appropriate levels and enjoy!

[How to attach clips to Uši microphones](#)

Technical specifications

Matched stereo pair of pre-polarized condenser microphones	
Cable	1.5 m (for each mic) with 3.5 mm (1/8") jack
Impedance	2.4 k Ω at 1kHz
Maximum input pressure level	~122 dB SPL
Sensitivity	-28 dB at 1kHz (± 3 dB)
Self-noise	14-17 dBA



From:

<http://knowledge.lom.audio/> - **LOM knowledge base**

Permanent link:

<http://knowledge.lom.audio/manuals/usi?rev=1470841726>

Last update: **2016/08/10 17:08**

