

# Elektrosluch



## How to use Elektrosluch

1. Plug your headphones into the output
2. Turn on the device with the volume knob
3. Move the device with the sensors pointing towards the electromagnetic field source
4. Adjust the volume for optimal listening experience. Start with the volume low and be careful with your ears.
5. Enjoy!

## Technical specifications

<b>Stereophonic electromagnetic listening device</b>	
<b>Power:</b>	9V battery (user replaceable)
<b>Headphone/Line Output</b>	3.5 mm (1/8") stereo mini jack
<b>Ext. input</b>	3.5 mm (1/8") stereo mini jack
<b>Maximum gain</b>	60 dB

From: <http://knowledge.lom.audio/> - LOM knowledge base

Permanent link: <http://knowledge.lom.audio/manuals/elektrosluch3?rev=1470848757>

Last update: 2016/08/10 19:05



