

DIY stereo bar (on budget)

Ingredients:

- unperforated DIN rail (available in electrical supply stores)
- 2 K&M 3/8" thumb screws (available on [Thomann](#))
- 3 K&M 3/8" thumb wheel (available on [Thomann](#))

Tools:

- drill for making the holes in the rail
- 9mm drill bit (but you can use a smaller one and extend it manually)



1. Adjust the size of the rail to your liking. For a 40 cm AB stereo bar I went with 42.5 cm

- Drill the three holes in top the rail. For 3/8" you can use 9mm drill bit on the sides and 10mm on the central one

- Screw in the screws into the holes and use thumbwheels as washers protecting the screws from falling out
- Use the third thumb wheel as a way to tighten the bar to your stand







From:
<http://knowledge.lom.audio/> - **LOM knowledge base**

Permanent link:
http://knowledge.lom.audio/research/diy_stereo_bar?rev=1523284741

Last update: **2018/04/09 16:39**

